Suggested Tools for installing Fabco, open curb StormBasin filters

- 1. StormBasin Type X unit(s): One for Type 1 and two for Type 3 open curb inlets. Each unit includes:
 - a. A plastic basin with aluminum frame
 - b. Two basin support flanges
 - c. One rubber/aluminum adjustable Splash guard
 - d. Two filter cartridges
- 2. One Fitting Kit: either a 9791-5-000 for Type 1 or a 9791-5D-000 for Type 3 Each kit includes:
 - a. Two basin support rails: 2"x 3" dimension supplied in one of two lengths
 - i. Type 1 typical length: 75"
 - ii. Type 3 typical length: 102"
 - b. Four wall mounting cleats
 - c. 16 strike anchors
- 3. StormBasins with "X" style Flanges are installed in a vault below the surface. Entry is typically through a 24" diameter manhole. The contractor must follow appropriate personnel and traffic safety protocols for this type of environment.

Tools:

- 1. Installation drawing 9791-5-100 (Type 1) or 9791-5D-100 (Type 3)
- 2. Tape measure 12' minimum
- 3. Electric miter saw 10" or 12" with metal (Aluminum) cutting blade
- 4. Electric generator >5500 running watts (Coleman Power Mate or equivalent)
- 5. ½" Hammer Drill (Milwaukee 0-500, 0-200 RPM 18V LokTor or equivalent)
- 6. 3/8" Concrete drill bit (bring spares)
- 7. Saws All for trimming pipes or other objects that extend into vault
- 8. Extension cord (s)
- 9. Work lights for sub-surface use
- 10. Dust and eye protection
- 11. Rubber boots for installer (s) the vaults may be wet and/or muddy
- 12. Hammers: 1 steel and 1 rubber
- 13. Open end wrench: 9/16"
- 14. Hand chisel to remove small bits of concrete
- 15. Screw gun/Drill with: 5/16 drive socket tip and a Phillips head tip (bring spares of both)
- 16. WD40 Spray apply to mounting flanges and dove-tail mounts prior to installation
- 17. Paint pen for marking drill hole patterns on concrete walls
- 18. Razor knife (s)
- 19. Manhole lifter
- 20. Metal scraper
- 21. Small hand brush for removing dirt/grit from ledges and frames
- 22. Short handle shovel
- 23. 2' Level
- 24. Ladder or other device to allow installer to enter vault through manhole opening
- 25. Empty buckets for cleaning loose material from vault interior